



CONFIDENTIAL PROPRIETARY INFORMATION

Reproductions of this data or the manufacturing of products from this data by anyone other than Spokane Industries, Inc. of Spokane Washington is strictly prohibited without written consent.

**TECHNICAL MANUAL**  
**GENERAL ATOMICS**  
**Fueler/Defueler Cart (FDC)**  
**Spokane Industries Model CNV200S-24V**

©COPYRIGHT 2007 By SPOKANE INDUSTRIES INC.

ALL RIGHTS RESERVED

This document discloses subject matter in which Spokane Industries, Inc has Proprietary rights and such subject matter shall not, without the written permission of Spokane Industries, Inc., be either (A) used, released or disclosed in whole or in part outside the government, (B) used in whole or in part by the government, for manufacture, or (C) used by a party other than the government, except for (1) emergency repair or overhaul work only, by or for the government, where the item or process concerned is not otherwise reasonably available to enable timely performance of the work, provided that release of disclosure hereof outside the government shall be made subject to a prohibition against further use, release of disclosure, or (2) release to a foreign government, or for emergency repair or overhaul work by or for such government under the conditions of (1) above. This legend shall be marked on any reproduction hereof in whole or in part.



# Limited Warranty Agreement Aviation Products

Spokane Industries (SI) of Spokane, Washington hereby Warrants to the purchaser (the Warrantee) that all products explicitly covered by this Warranty Agreement have been thoroughly inspected upon completion and that they and their component parts are free of defects in materials and workmanship. SI further warrants that in the event the product fails due to defects in materials and/or workmanship within a period of twenty-four (24) months from the effective date of this warranty that SI will provide replacement parts free of charge except for those components which are covered by an Original Equipment Manufacturer's (OEM) Warranty, in which case coverage will be provided by that OEM.

## Coverage

The SI Sealvac Products Limited Warranty Agreement covers all products manufactured for use as Ground Support, Defueling equipment. Certain components of these products are manufactured by third party Original Equipment Manufacturers (OEMs) and are covered by these manufacturers' Warranties. SI Warranty coverage is contingent upon proper installation, operation, maintenance and repair of the product. Refer to the appropriate manuals and documentation for assistance. In cases of uncertainty, SI must be consulted prior to any service work being performed. Failure to do so may result in the termination of Warranty coverage.

## Terms and Conditions

### REQUESTS FOR WARRANTY COVERAGE

Requests for Warranty Coverage should be addressed to the SI, Spokane Metal Products Customer Support and Service Department N. 3808 Sullivan Road, Building #4, Spokane, WA, 99216, 800-541-360, Fax: 509-927-0826. Please provide the Model Number, Ship Date, Original Purchaser, and Point of Installation, and, if possible, our original Sales Order number. The Service Department will make a Warranty determination based upon this information and our internal records. If Warranty coverage is in effect replacement parts will be sent provided that credit terms have been established. If Warranty coverage is not in effect, the cost of replacement parts will be quoted.

### TRANSFERABILITY

This warranty is extended only to the original purchaser named on this warranty certificate and is not transferable without the express written consent of SI. Transferability is contingent on the product being in warrantable condition. SI reserves the right to verify product warrantability by whatever means is deemed appropriate, and the right to refuse to transfer the warranty with or without cause. Warranty transfer requests must be made in advance of the sale or transfer of the product. SI accepts no responsibility for any costs associated with the transfer of existing warranties including any costs associated with verification of product warrantability. Requests for Warranty transfers should be addressed c/o SI, Spokane Metal Products Customer Support and Service Department at the address above.

### RETURN OF WARRANTY PARTS ("EXCHANGE")

For the purposes of quality assurance, SI requires that certain parts and assemblies covered under the SI Limited Warranty Agreement be returned by the Warrantee upon receipt of replacements (known as "Exchange"). In these cases, SI will authorize the shipment of replacement parts immediately and provide a Returned Merchandise Authorization (RMA) number along with a full retail invoice for the replacement parts pending receipt of the Warranty ("defective") parts. The Warranty parts must be returned to SI within 30 days with the RMA number CLEARLY marked on the shipping materials. At this time SI will inspect the Warranty parts to verify Warranty coverage. If the Warranty parts are deemed defective due to materials and workmanship SI will issue a full credit for the replacement parts. If the Warranty parts are not returned within thirty days the Warrantee's account will not be credited. Payment in full is then due and subject to the standard terms and conditions of SI credit.

\* In cases where returned parts are deemed **not to be defective**, SI reserves the right to **refuse to cancel the applicable invoice**.

\* Exchange parts must be properly packed and sealed and shipped to SI by prepaid freight. Under no circumstances does SI accept C.O.D. shipments.



\* *SI Warranty replacement parts are provided subject to the terms and conditions of the SI Sales and Service Agreement which states that where no other Warranty coverage is in place, Service and Warranty parts are covered by a ninety day limited Warranty.*

#### **LIMITATIONS**

*The following limitations apply to the SI Limited Warranty Agreement:*

- \* *SI shall not be liable under any circumstances for any incidental or consequential damages including, but not limited to, loss of time, inconvenience, expenses incurred by purchaser in order to remedy defects, or liability purchaser may have with respect to any other person for loss or damage arising from the operation of the product or the product's failure to operate in any way, or any other type of consequential damage or economic loss.*
- \* *This warranty is limited to defects in materials and workmanship. SI assumes no liability whatsoever for damages arising from the inability of the product to perform a certain task. Damage arising during shipping and handling, improper installation, use, maintenance, repair, or any unauthorized modifications, whether performed by qualified service personnel or not, neglect, Acts of God, etc., are expressly excluded. **In any case, SI's liability shall be limited only to the provision of suitable replacement parts for those which failed due to defects in materials and workmanship. Incidental damage resulting from the failure, and labor costs associated with the repair and/or replacement of the product, its assemblies, and component parts, are excluded.***
- \* *SI reserves the right to limit or terminate warranty coverage in instances where repeated product failures are a result of failure to correct operating conditions which are in any way abnormal or exceed operating condition specifications. It is the purchaser's responsibility to remedy such conditions as may be likely to cause initial and/or repeated failures of the equipment. SI assumes no responsibility whatsoever for any costs incurred for this purpose.*
- \* *The SI Limited Warranty Agreement covers only replacement parts supplied by SI. SI makes every reasonable effort to ensure an adequate supply of replacement parts. However, in cases where the exact replacement part is no longer available, SI reserves the right to provide a suitable substitute. Components such as batteries, which are subject to normal wear and tear are pro-rated under the provisions of this Warranty. Warranty coverage shall be pro-rated according to the amount of Warranty coverage remaining.*

#### **EXCLUSIONS**

*The following exclusions apply to the SI Limited Warranty Agreement:*

- \* *The SI Limited Warranty Agreement applies only to authentic new and, where applicable, refurbished products. Products sold "As Is", demonstration units, and any other products subjected to previous use are explicitly excluded.*
- \* *The SI Limited Warranty Agreement excludes any and all parts and assemblies which are covered by another manufacturer's Warranty (see above).*
- \* *This Limited Warranty Agreement constitutes the complete and entire SI Warranty statement. Any items and/or circumstances not expressly covered by this Warranty Agreement are hereby excluded. This includes, but is not limited to, such additional offerings as SI may make available from time to time. These offerings are independent of this Agreement and, as such, do not in any way extend, modify, or otherwise alter the coverage, terms, conditions, limitations, and exclusions as they are set forth here unless **explicitly stated**.*
- \* *The failure to observe any and all of the terms and conditions of this warranty will render it null and void.*
- \* *Although all reasonable precautions are taken to ensure that shipping damage is avoided, any damage incurred during the shipment and installation of the product is explicitly excluded. Any and all damage during shipment is the sole responsibility of the transportation carrier(s). Product should be thoroughly inspected prior to acceptance from the freight carrier. All SI products are shipped F.O.B. Spokane Washington.*
- \* *This Warranty is in lieu of all other warranties whatsoever, express, implied and statutory, including, without limitation, the implied warranties of merchantability and fitness for a particular purpose, and all such warranties express or implied, shall be excluded from this transaction and shall not apply to the goods sold. Product should be thoroughly inspected prior to acceptance from the freight carrier. All SI products are shipped F.O.B. Spokane Washington.*

*Warranty inquiries are welcome and should be addressed to:*

SI Service Department  
Spokane Industries, Spokane Metal Products Division  
Spokane Industrial Park Building 4  
N3808 Sullivan Rd.  
Spokane, Washington 99216  
(800) 541-3601

## TABLE OF CONTENTS

	<b>Table of Contents</b>	Page. 4
<b>Section</b>		
<b>1.0</b>	<b>Fueler/Defueler Cart Specifications</b>	Page. 5
<b>2.0</b>	<b>Safety Guidelines</b>	Page. 6
<b>3.0</b>	<b>Controls and Indicators</b>	Page. 7
<b>4.0</b>	<b>Basic Operation</b>	Page. 8
4.2	Pre-Towing requirements/ checklist	Page. 8
4.3	Operational Definitions	Page. 9
4.4	Top Loading Fuel into the FDC	Page. 9
4.5	Fueling the aircraft	Page. 9
4.6	Defueling the aircraft	Page. 10
4.7	Fuel Moisture Removal (Tank & Filter housings)	Page. 11
<b>5.0</b>	<b>Inspection and Maintenance</b>	Page. 12
<b>6.0</b>	<b>Troubleshooting</b>	Page. 13
<b>7.0</b>	<b>Parts Breakdown</b>	Page. 14
<b>Drawing #</b>	<b>1</b> CNV200S-24V Overview, Component Identification	
	<b>2</b> Pump Component Overview	
	<b>3</b> Front Undercarriage	
	<b>3.1</b> Tow Bar Pivot Assembly	
	<b>3.2</b> King Pin Assembly	
	<b>3.3</b> Front Hub Assembly	
	<b>4</b> Rear Undercarriage	
	<b>4.1</b> Rear Axle	
	<b>4.2</b> Brake Assembly	
	<b>4.3</b> Rear Hub & Drum Assembly	
	<b>5</b> Wheel & Tire Assembly (see B-Range)	
	<b>6</b> De-fuel Adaptor	

## Section 1.0 Introduction

- 1.1 This operating manual contains information necessary for the operation and maintenance for the unit labeled by General Atomics as the Fueler/Defueler Cart (FDC). Spokane Industries model number is CNV200S-24V. **Throughout this manual the unit will be referred to as the FDC.** The FDC is designed to provide a portable, self-contained fueling/defueling system for the UAV program.

**Table 1.0 Specifications for Fueler/Defueler Cart (FDC)**

<b>Dimensions</b>	
Length — (Tow bar up)	122 inches
Width	58 inches
Height	47 inches
Weight—Empty	Estimated at less than 1500 lbs.
<b>Capacity</b>	200 U.S gallons
<b>Tank Construction</b>	Double wall tight wrap, T304 stainless steel
<b>Under Carriage rating</b>	4,000 lbs.
<b>Tires/ Wheels</b>	B Range tire 20.5 X 8.0 – 10 with tube, split wheel
<b>Brakes</b>	Drum Style, manually operated
<b>Batteries -2 each</b>	12 Volt, Group 24 - wired in series (24 volt output)
<b>Battery Charger</b>	120 Volt AC input/ 12 Volt DC dual output
<b>Pump</b>	Fill-Rite model 4401, 24 Volt DC, 20 GPM before plumbing
<b>Fuel Meter</b>	Fill-Rite model 901
<b>Fuel Filter housing</b>	Model # Velcon VF-61EP½
<b>Fuel Filtration, fueling/defueling</b>	Flow Rate - Jet Fuel < 35 GPM Avgas < 45 GPM
Coalescer Element	Model # OS-51288 (Velcon) .5 micron filtration
Monitor Element	Model # CDF-210N (Velcon) .5 micron filtration
<b>Fueling Hose</b>	25 feet X ¾ inch ID, Goodyear Wingcraft (Non-certified)
<b>Fueling Nozzle</b>	¾ inch automotive
<b>Defueling adapter</b>	½ inch hose assembly with connection for aircraft
<b>Lifting/ securing for shipment</b>	Forklift tunnels/ 1000 lb. rated tie downs @ each corner

## **Section 2.0 Safety Guidelines for Fueler/ Defueler Cart (FDC)**

**2.1** Within this manual are guidelines and safety recommendations for use of the FDC. It is the responsibility of the end user to completely read this manual and comply with all local, state and federal laws and regulations applicable for fueling and defueling aircraft.

**2.2** Spokane Industries Inc. is not responsible for industry specific information on safety management, employment safety, health standards, safety codes, etc. Contact your local safety manager or industrial safety representative.

**NOTE:** Spokane Industries does not allow any field modifications to be performed by the user without written permission from a Spokane Industries representative. Unauthorized field modifications may result in an unsafe condition for either personnel or equipment and will void the manufacturers warranty.

**2.3** It is the responsibility of the end user to ensure persons operating this equipment:

- Are trained, authorized and permitted to use the equipment.
- Have physical and the mental ability to operate this equipment safely.
- Are aware of the potential hazards associated with this equipment, i.e. static electricity, electrical shock, fuel spills, pinch points.

## Section 3.0      CONTROLS & INDICATORS

3.1      The Controls and Indicators section is designed to provide a description of the various controls and indicators found on the FDC. All physical references are made from the rear looking forward towards the tow bar.

**Table 3.0      CONTROLS & INDICATORS FOR THE FDC**

Tow bar - Lunette style, removable	Located at the forward end of the FDC. Tow bar can be locked upright.
Liquid level gauge	Located on top of tank. Indicates level of fuel in 1/4 tank increments .
Parking Brake Handle	Located on left side . Used to set park brake during operation and storage. Not intended to STOP the unit underway, this is a parking brake system only.
Low Point drain (moisture drain valve)	Located below pump cabinet, aft side. Used to remove moisture from tank or take samples.
<b>CONTROL PANEL AREA</b>	<b>(located left, rear)</b>
Fuel/ Defuel T-Handle.	Located left side of control panel. Controls 2 each 3-way ball valves that direct fluid direction into or out of main tank.
Differential pressure Gauge—2 each	Separate gauges for either Coalescer or Monitor filter element. Indicates degree of blockage of each filter element. Red at 15 PSI differential pressure
Compound Gauge	Monitors Fuel/ Defuel Hose pressure and suction. Fueling operations—measured in PSI. Defueling operations—measured in inches of mercury (Hg)
<b>PUMP AREA</b>	<b>(located at rear)</b>
Fuel Filter Housings — 2 each, located aft side of pump cabinet. <b>Monitor</b> Housing located on right Side <b>Coalescer</b> Housing located on left side	Each housing contains a filter element assembly, filter housing air bleeder and housing drain pet-cock. Ports for differential pressure gauge hoses located on top of housing .
Fuel Filter Elements—2 types are installed. <b>Monitor</b> (water absorbing) Located inside right side filter housing  <b>Coalescer</b> (water separating) Located inside left side filter housing.	- <b>Monitor</b> elements are rated up to 10 GPM per element, 5 at a time are installed into the housing for a 50 GPM capability. Monitors absorb water into the filter media. - <b>Coalescer</b> element is rated at 35 GPM for jet fuel, 45 GPM for Avgas, it is a single cartridge element designed to separate water from the fuel.
Tank-to-Pump Valve	Master valve allowing fuel into or out of main tank.
Battery Box	Houses two 12 volt batteries 25 Amp thermal circuit breaker with indicator 24 VDC Battery Charge Condition Indicator Battery Charger (externally mounted) Master ON/OFF switch

## **Section 4.0 BASIC OPERATION OF THE FDC**

- 4.1** This section contains information necessary for the safe operation and maintenance of the FDC. The FDC is designed to provide a portable, safe, self-contained, fueling/defueling system .
- 4.2 Pre-Towing requirements.** Items in Table 4.0 need to be accomplished before towing the FDC .

**CAUTION:**            **DO NOT back up the FDC using a tow vehicle.**  
**Damage to under carriage, steering assembly or tow bar may occur.**

**Table 4.0            PRE-TOWING SAFETY CHECKLIST**

<b>ITEM DESCRIPTION</b>	<b>PRE-TOWING CHECK</b>	<b>VISUAL INSPECTION</b>	<b>CORRECTIVE ACTION</b>
<b>Tires, Tire Pressure</b>		Check for damage and proper tire inflation.	Replace tire if damaged. Inflate to manufacturers specifications on tire side-wall
<b>Brakes</b>		Ensure brakes lever is released	Pull handle rearward
<b>Tank</b>		Visually inspect for cracks or leaks. Ensure Man way cover is closed and latched. Ensure tank is securely fastened to the rolling undercarriage.	Repair cracks or leaks before use. Tighten fasteners if loose.
<b>Hoses, Nozzle, Grounding Clamps and wires</b>		Ensure all hoses and ground wires clamps are secured for transportation. Inspect hoses, clamps and wires for service-ability.	Replace hoses, grounding clamps or wires before use if found to be beyond repair.
<b>Valves</b>		Visually inspect to ensure all valves are in the closed position. Check for leaks.	If leaks are found, repair or replace item before using.
<b>Pump cabinet doors</b>		Ensure all cabinet doors are closed and latched.	

#### 4.3 Operational Definitions.

<b>Top Loading</b>	Loading fuel by using the Man way cover for access to the tank.
<b>Fueling</b>	Actions requiring fuel to be discharged through the FDC fuel nozzle.
<b>Defueling</b>	Actions that involve removing fuel from an item other than the FDC
<b>CAUTION</b>	Indicates an operation or condition that, if not observed, could result in equipment or property damage.
<b>WARNING</b>	Indicates an operation or condition that, if not observed, could result in possible injury or death.

#### 4.4 TOP LOADING:

**WARNING: No overfill protection, visually monitor tank fluid level during Top Filling operations**

- A. Set Brake Lever forward
- B. Chock tires if chocks are available

**CAUTION: Improper grounding may result in an ignition source.**

- C. Connect static ground clamp to approved grounding point.
- D. Ensure Tank to Pump valve is closed.
- E. Open 10 inch Man way cover.
- F. Ground Source loading hose to FDC tank opening
- G. Fill tank to required capacity.
- H. Remove hose and ground connection.
- I. Close and latch Man way cover.
- J. Disconnect and store static ground clamps.

#### 4.5 FUELING THE AIRCRAFT:

**WARNING: Never operate the FDC in an enclosed area. Proper ventilation must be maintained at all times. All fuels are flammable, do not allow sources of ignition within 50 feet of the FDC.**

- A. Set brakes by moving Brake lever forward.
- B. Chock tires if chocks are available.

**CAUTION: Improper grounding may result in an ignition source.**

- C. Connect static ground wire with clamp to earth grounding point and ground wire with pin to approved aircraft grounding point.
- D. Open cabinet doors.

*4.5 Fueling, continued next page*

9

- E. From right side of pump cabinet reach in and open Tank-to-Pump valve, (large valve located forward of battery box) handle will point downward.

**WARNING: Do not attempt to charge batteries while using the FDC 24 Volt electric fuel pump, damage to charger will occur.**

- F. Uncoil and fully extend hose.
- G. Remove Nozzle from stowed position and attach to hose end.
- H. Reset meter.
- I. At the control panel ensure T-Handle is pushed IN for fueling operations.
- J. On battery box turn main power switch ON by turning clockwise.
- K. Ensure battery charge indicator indicates enough charge for operation.
- L. Turn main pump ON by moving ON/OFF lever up.
- M. Open aircraft fuel tank and insert nozzle.

**NOTE: Periodically monitor differential pressure gauges during fueling operations. This allows real time reading of filter contamination level. Red scale begins at 15 PSI differential pressure.**

- N. Fill tank to desired capacity.
- O. Remove nozzle, close fuel tank and turn off pump.
- P. Turn main power switch OFF at battery box.
- Q. Remove nozzle and stow in nozzle holder.
- R. Recoil hose and store.
- S. Close Tank-to-Pump valve (handle will be horizontal)
- T. Close and secure pump cabinet doors.

#### **4.6 DEFUELING THE AIRCRAFT:**

**WARNING: Never operate the FDC in an enclosed area. Proper ventilation must be maintained at all times. All fuels are flammable, do not allow sources of ignition within 50 feet of the FDC.**

**WARNING: No overfill protection during defueling operations. Ensure there is sufficient tank capacity to receive the amount of fuel being removed from the aircraft.**

- A. Set brakes by moving Brake lever forward.
- B. Chock tires if chocks are available.

**CAUTION: Improper grounding may result in an ignition source.**

- C. Connect static ground wire with clamp to earth grounding point and ground wire with pin to approved aircraft grounding point.
- D. Remove aircraft fuel port access panel
- E. Open cabinet doors.
- F. From right side of pump cabinet reach in and open Tank-to-Pump valve, (large valve located forward of battery box) handle will point downward.

*4.6 Defueling, continued next page*

- H. Uncoil and fully extend hose.
- I. Attach defuel adapter to end of hose.
- J. Connect defuel adapter to appropriate defuel port on the aircraft. Ensure adapter valve is closed.

**CAUTION:** Ensure proper venting of the aircraft fuel cell is accomplished prior to beginning defuel operations. Damage to aircraft or aircraft fuel cell may occur if venting is not accomplished.

- K. Reset fuel meter.
- L. At the control panel ensure T-Handle is pulled OUT for defueling operations.
- M. Ensure battery charge indicator indicates enough charge for operation.
- N. On battery box turn main power switch ON by turning clockwise.
- O. Turn main pump ON by moving ON/OFF lever up.
- P. Open fuel adapter valve, handle will be inline with adapter hose.
- Q. Monitor fuel meter to remove desired quantity of fuel.
- R. When desired quantity is reached close fuel adapter valve.

**NOTE:** Repeat steps K thru R if defueling any other fuel cells on the aircraft

- S. Turn off main pump.
- T. Disconnect fuel adapter from aircraft and remove from hose end, stow in storage cabinet.
- U. Turn off main battery switch.
- V. Recoil hose and store.
- W. Close Tank-to-Pump valve (handle will be horizontal)
- X. Close and secure pump cabinet doors.

#### 4.7 FUEL MOISTURE REMOVAL: Low Point Drain/ Fuel Filter Housings.

The low point drain is located between the pump cabinet and main tank at the lowest point. A brass valve with lever manually discharges a fuel/water sample or to drain the tank. The lever is spring loaded in the CLOSED position.

- A. Set brakes by moving Brake lever forward.
- B. Chock tires if chocks are available.
- C. Procure approved fuel container that will assure containment for amount of liquid to be drained. Place under Low Point Drain Valve.
- D. Open low point drain valve by pushing lever downward.
- E. Drain sufficient quantity to remove water or attain sample.
- F. Release handle to shut off flow.

**Fuel Filter Housing** - drain using same type of container

- A. Open air vent on top of housing. (turn counter clockwise).
- B. Place container under housing and open drain. (turn clockwise as viewed from the top).
- C. Drain sufficient quantity to remove water from housing.
- D. Close drain.

## SECTION 5.0 INSPECTION AND MAINTENANCE

5.1 This section provides the basic requirements to maintain the FDC. The chassis and tank of the FDC requires minimal preventive maintenance. The tow bar and steering spindles use Oil Lite bronze bushings which require NO lubrication.

**Table 5.0 Inspection Intervals and Component Maintenance Guide**

COMPONENT	INTERVAL	CRITERIA	MAINTENANCE
Fueling Nozzle	Each use	- Cracks, Leaks	- Replace before using
Fuel Meter	Each use	- Leaks	- Repair or replace before using
Fuel Hose	Each Use	- Cuts, leaks	- Replace before using
Fuel Filter Housings	Each use	- Cracks, leaks	- Replace if cracked, determine cause of leaks and repair if possible, if leaks can not be repaired replace housing.
Pump cabinet plumbing	Each use	- Inspect all plumbing lines, tubes and clamps for cracks and leaks	- Cracks are unserviceable and item shall be replaced. Leaks should be repaired if possible, if item can not be repaired then replacement is due.
12 Volt batteries	6 Months	- Inspect battery cell fluid level	- Service as required - <b>To service batteries</b> disconnect 2 bolts holding pump cabinet to frame outboard of the filter housings, lift cabinet up and off, disconnect fuel pump wiring harness from battery box, remove battery box from right side of pump frame, place on level ground, remove box cover - Service batteries.
Wheel bearings	2 years	- Grooves, chips, discoloration	- Lubricate using approved wheel bearing grease. Slight discoloration is allowed. Severe discoloration, chips or grooves in bearing surfaces is cause for replacement.
Brakes	Each use	- Proper engagement	- Adjust as needed

## **SECTION 6.0 TROUBLESHOOTING THE FDC**

**6.1** The following troubleshooting guidelines are designed to cover most common types of problems with probable solutions to repair the condition.

**TABLE 6.1 TROUBLE SHOOTING FOR FUELING/ DEFUELING OPERATIONS**


<b>FAULT</b>	<b>POSSIBLE CAUSE</b>	<b>CORRECTIVE ACTION</b>
Low/ No discharge pressure at fuel nozzle	<ul style="list-style-type: none"> <li>- Low battery charge</li> <li>- Fuel filter(s) restricted</li> <li>- Tank-to-Pump valve partially open</li> <li>- Fuel/Defuel T-handle not pushed in</li> <li>- Y-Strainer screen restricted</li> </ul>	<ul style="list-style-type: none"> <li>- Charge batteries</li> <li>- Inspect and replace if needed</li> <li>- Ensure valve is open (handle vertical)</li> <li>- Ensure T-handle is pushed in completely</li> <li>- Remove/ clean Y-Strainer screen</li> </ul>
Low/ No Defueling Capability	<ul style="list-style-type: none"> <li>- Low battery charge</li> <li>- Fuel filter(s) restricted</li> <li>- Tank-to-Pump valve partially open</li> <li>- Fuel/Defuel T-handle not pulled out</li> <li>- Y-Strainer screen restricted</li> </ul>	<ul style="list-style-type: none"> <li>- Charge batteries</li> <li>- Inspect and replace if needed</li> <li>- Ensure valve is open (handle vertical)</li> <li>- Ensure T-handle is pulled out completely</li> <li>- Remove/ clean Y-Strainer screen</li> </ul>
24 Volt pump – weak or will not work	<ul style="list-style-type: none"> <li>- Low/ No battery charge</li> <li>- Battery terminals/ cables corroded</li> <li>- Battery Cell(s) fluid low</li> <li>- Main Power switch in OFF position</li> <li>- Pump has internal damage</li> <li>- Pump has reached duty cycle</li> <li>- Circuit breaker has tripped</li> </ul>	<ul style="list-style-type: none"> <li>- Fully charge batteries</li> <li>- Inspect &amp; clean, replace if necessary</li> <li>- Service cell(s) with distilled water</li> <li>- Turn Main Power switch ON</li> <li>- Replace pump</li> <li>- Wait 30 minutes and retry</li> <li>- Wait 30 minutes and retry</li> </ul>
Fuel Meter has no indication of flow	<ul style="list-style-type: none"> <li>- Main pump not turned ON</li> <li>- Tank-to-Pump valve CLOSED</li> <li>- Main tank empty</li> <li>- Fuel Meter internally broken</li> </ul>	<ul style="list-style-type: none"> <li>- Turn ON pump</li> <li>- OPEN Tank-to-Pump valve</li> <li>- Load fuel into tank</li> <li>- Replace fuel meter</li> </ul>

## **SECTION 7.0 PART BREAKDOWN DRAWINGS**

The following drawings are supplied to assist the user in component identification and parts re-ordering.

### **DRAWING #**

- 1** CNV200S-24V Overview, Component Identification
- 2** Pump Component Overview
- 3** Front Undercarriage
  - 3.1** Tow Bar Pivot Assembly
  - 3.2** King Pin Assembly
  - 3.3** Front Hub Assembly
- 4** Rear Undercarriage
  - 4.1** Rear Axle
  - 4.2** Brake Assembly
  - 4.3** Rear Hub & Drum Assembly
- 5** Wheel & Tire Assembly (see B-Range)
- 6** De-fuel Adaptor



Parts List

ITEM	QTY	P.N.	DESCRIPTION	WT.
1	1	9923-10	TANK WELDMENT	205.41
2	1	04-01540	LEVEL GAUGE	.08
3	1		PUMP COMPONENTS (SEE FIGURE #2 )	546.92
4	2	01-903S	FORK LIFT POCKETS	12.19
5	4	P.D.	TIE DOWN RINGS	.38
6	4	07-10201	WHEEL, TIRE, AND TUBE ASSEMBLY	31.90
7	2	04-1036	GROUNDING REEL	9.38
8	1	08-1029 R1	FRONT UNDERCARRIAGE	163.32
9	1	04-2716	MANWAY, 16"/10" BETTS PPVL716DXV DOT APPROVED	20.27
10	2	04-0700	FIRE EXT. 5# PURPLE-K 20 B:C	4.06
11	2	04-0701	FIRE EXT. BRACKET #807	2.83




PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance:except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°


<b>CNV200S-24V UNIT CONFIGURATION</b>	
PN: 9923-10	FIG. #1

Drawn: AL	Date:8/27/2007	Size: A	Scale: NTS	Sheet 1 of 1
-----------	----------------	---------	------------	--------------



Parts List				
ITEM	QTY	P.N.	DESCRIPTION	WT.
1	1	P.D.	FILLRITE PUMP, 24V,	
2	2	P.D.	FRAME ASSEMBLY	81.20
3	2	P.D.	DIFFERENTIAL PRESSURE GAUGES	.66
4	1	P.D.	COMBINATION GAUGE, PRESSURE AND VACUUM	1.77
5	2	P.D.	VF-61 FILTERS	.08
6	1	P.D.	FILLRITE METER	.00

	SPOKANE INDUSTRIES PO Box 3303 Spokane, WA. 99220 800-541-3601			
	Tolerance: except as noted x/x=± 1/8" .xx=± .03" .xxx=± .005" ANG=± 1°			
CNV200S-24V PUMP COMPONENTS			PN: 9923-10 FIG. #2	
Drawn: AL	Date: 8/27/2007	Size: A	Scale: NTS	Sheet 1 of 1



Parts List

ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
1	1	07-1053	FRONT AXLE	Steel,Mild	55.45
2	2	04-1055	HAND GRIP	Rubber	.05
3	1	07-1103	TOW BAR	Various	21.65
4	2	08-1011	FRONT HUB ASSEMBLY SEE FIGURE 3.3	Various	8.62
5	6	02-12041	NUT, NYLON INSERT, 1/2" UNC	Steel, Mild	.05
6	4	02-1503	HEX BOLT, 1/2" UNC x 4 1/2" LG.	Steel, Mild	.31
7	2	06-1023	PAD, MOUNTING	Rubber	.75

**SI** SPOKANE  
INDUSTRIES

PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance:except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

**FRONT UNDERCARRIAGE**  
**CNV200S-24V**

PN: 08-1029R1

FIG#3


Drawn: AL

Date:10/23/2006

Size: A

Scale: NTS

Sheet 1 of 1



Parts List					
ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
1	1	02-12071	NUT, NYLON INSERT, 3/4-16 UNF	Steel, Mild	.00
2	2	03-1014	BUSHING, STEERING ARM	Bronze	.00
3	1	02-1207	JAM NUT, NYLON INSERT, 3/4-16 UNF	Steel, Mild	.08
4	1	07-1104	STEERING ARM, 200 ONLY		.00
4	1	07-1052	STEERING ARM, 400 & 600 ONLY		.00
5	1	02-1501	HEX BOLT, 5/16-18 x 4 1/2" LG.	Steel, Mild	.00
6	1	02-1300	PIN, COTTER	Steel, Mild	.00
7	1	04-1054	SPRING	Steel, Mild	.12
8	1	07-1020	TOE LATCH		.00
9	1	02-11072	FLATWASHER, 3/4"	Steel, Mild	.00
10	2	03-1015	BUSHING, TIE ROD	Bronze	.00
11	1	02-1201	NUT, NYLON INSERT, 5/16-18	Stainless Steel	.00
12	1	02-1304	HITCH PIN	Steel, Mild	.00
13	2	02-12041	NUT, NYLON INSERT, 1/2" UNC	Steel, Mild	.06
14	1	07-1016	STEERING ARM, LOWER PLATE, 200 ONLY		.00
14	1	07-1046	STEERING ARM, LOWER PLATE, 400 & 600 ONLY	Steel, Mild	.00
15	2	02-1502	BOLT, 1/2-13 x 1 3/4" LG.	Steel, Mild	.00
16	1	07-10371	TIE ROD, 200 ONLY, (07-1005 TIE ROD, 400 & 600 ONLY)	Steel, Mild	.00

**SI SPOKANE INDUSTRIES**


PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance: except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

**FRONT UNDERCARRIAGE  
CNV200S-24S**

**FIG. #3.1**

Drawn: AL | Date: 11/30/2004 | Size: A | Scale: NTS | Sheet 1 of 1



3	1	02-12141	NUT, 3/4-16 UNF	Steel, Mild	.13
6	1	02-12071	NUT, NYLON INSERT, 3/4-16 UNF	Steel, Mild	.17
7	2	03-1013	BUSHING, KING PIN	Bronze	.36
4	2	02-11072	FLATWASHER, 3/4"	Steel, Mild	.10
10	1	02-12131	NUT, NYLON INSERT	Steel, Mild	1.21
9	1	02-11131	WASHER, FLAT	Steel, Mild	.43
5	1	03-1016	ROD END, BALL JOINT		1.32
8	1	07-10105	KING PIN		5.24
2	1	07-1009	HOUSING, KING PIN		8.17
1	1	07-11071	FRONT AXLE		67.95
ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
Parts List					

**SI SPOKANE INDUSTRIES**

PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance: except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

**FRONT UNDERCARRIAGE**  
**CNV200S-24V**

PN: 08-1029R1

FIG. # 3.2


Drawn: AL

Date: 11/9/2006

Size: A

Scale: NTS

Sheet 1 of 1



Parts List

ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
1	1	04-1017	HUB, FRONT AXLE	Iron	6.48
2	1	04-1016	CUP, OUTER BEARING	Steel, Mild	.08
3	1	04-1014	CONE, OUTER BEARING	Steel, Mild	.17
4	1	02-12055	WASHER	Steel, Mild	.05
5	1	02-1205	NUT, CASTLE	Steel, Mild	.16
6	1	04-1015	CUP, INNER BEARING	Steel, Mild	.18
7	1	04-1013	CONE, INNER BEARING	Steel, Mild	.24
8	1	04-1012	SEAL, BEARING	Steel, Mild	.04
9	1	04-1019	CAP, HUB	Steel, Mild	.10
10	5	02-1017	STUD	Steel, Mild	.16
11	1	02-1303	PIN, COTTER	Steel, Mild	.01
12	5	04-1021	NUT, LUG	Steel, Mild	.06



PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance: except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

FRONT HUB ASSEMBLY

PN: 08-1011

FIG. #3.3

Drawn: jay

Date: 10/18/2005

Size: A

Scale: NTS

Sheet 1 of 1



Parts List

ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
1	1	08-1030ZR2	REAR AXLE ASSEMBLY SEE FIGURE #4.1		49.68
2	1	08-1031X	BRAKE ACTUATOR ASSEMBLY		16.90
3	2	08-1007R	BRAKE ASSEMBLY SEE FIGURE #4.2		5.23
4	2	08-10111	REAR HUB & DRUM ASSEMBLY SEE FIGURE #4.4		15.09
5	2	08-12050	BRAKE LINKAGE SEE FIGURE #4.3		1.12
6	2	06-1012	REAR MOUNT PAD	Rubber	.27
7	1	04-1055	HAND GRIP	Rubber	.05

**SI** SPOKANE  
INDUSTRIES

PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance: except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

REAR UNDERCARRIAGE  
200 GALLON MODELS

PN: 08-10101

FIG. #4


Drawn: jay

Date: 11/16/2005

Size: A

Scale: NTS

Sheet 1 of 1



Parts List

ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
1	1	05-1054	REAR AXLE	Steel, Mild	27.72
2	2	07-1010R	REAR SPINDLE		9.39
3	2	02-1505	BOLT, HEX, 1/2" UNC x 4" LG.	Steel, Mild	.28
4	6	02-12041	NUT, NYLON INSERT, 1/2" UNC	Steel, Mild	.05
5	2	02-10041	BOLT, HEX, 1/2" UNC x 1 1/2" LG.	Steel, Mild	.13
6	2	02-1014	NUT, HEX, 1/2" UNC	Steel, Mild	.04
7	2	02-1203	NUT, HEAVY HEX, 1/2" UNC	Steel, Mild	.07
8	8	02-15035	BOLT, 3/8 UNC x 1" LG.	Steel, Mild	.05
9	8	02-1103	LOCK WASHER, 3/8"	Steel, Mild	.01
10	8	02-1216	HEX NUT, 3/8"-UNC	Steel, Mild	.02
11	4	02-1503	HEX BOLT, 1/2" UNC x 4 1/2" LG.	Steel, Mild	.31

**Si** SPOKANE  
INDUSTRIES

PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance: except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

REAR AXLE  
200 GALLON MODELS

PN: 08-1030ZR2

FIG. #4.1

Drawn: jay


Date: 11/16/2005

Size: A

Scale: NTS

Sheet 1 of 1

SHOWN OUT OF POSITION  
FOR CLARITY



Parts List

ITEM	QT	P.N.	DESCRIPTION	MATERIAL	WT.
1	1	04-1064R	BACK PLATE	Steel, Mild	2.11
2	1	04-1030R	CAM LEVER	Steel, Mild	.32
3	1	02-10017R	HEX HEAD CAP SCREW, 5/16"-UNF 1 1/2" LG.	Steel, Mild	.04
4	1	02-12011	NUT, 5/16"-UNF GRADE 8	Steel, Mild	.01
5	1	02-11011	LOCK WASHER, 5/16"	Steel, Mild	.00
6	1	04-10265R	RETURN SPRING	Steel, Mild	.06
7	2	04-1026R	BRAKE SHOE HOLD DOWN SPRING	Steel, Mild	.01
8	2	04-1065R	BRAKE SHOE	Steel, Mild	1.12
9	1	04-1028R	CAM	Steel, Mild	.43

**SI** SPOKANE  
INDUSTRIES

PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance:except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

**BRAKE ASSEMBLY**

PN: 08-1007R

FIG. #4.2


Drawn: jay

Date:10/11/2005

Size: A

Scale: NTS

Sheet 1 of 1



Parts List

ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
1	1	05-1020	HUB, REAR AXLE	Steel, Mild	6.15
2	1	04-1016	CUP, OUTER BEARING	Steel, Mild	.08
3	1	04-1014	CONE, OUTER BEARING	Steel, Mild	.17
4	1	02-12055	WASHER	Steel, Mild	.05
5	1	02-1205	NUT, CASTLE	Steel, Mild	.16
6	1	02-1303	PIN, COTTER	Steel, Mild	.01
7	1	04-1019	CAP, HUB	Steel, Mild	.10
8	1	04-1015	CUP, INNER BEARING	Steel, Mild	.18
9	1	04-1013	CONE, INNER BEARING	Steel, Mild	.24
10	1	04-1012	SEAL, BEARING	Steel, Mild	.04
11	5	02-1017	STUD	Steel, Mild	.16
12	1	05-1021	DRUM, BRAKE	Steel, Mild	6.80
13	5	04-1021	NUT, LUG	Steel, Mild	.06



PO Box 3303 Spokane, WA. 99220 800-541-3601


Tolerance:except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

REAR HUB & DRUM ASSEMBLY

PN: 08-10111

FIG. #4.4

Drawn: jay Date:11/30/2005 Size: A Scale: NTS Sheet 1 of 1



Parts List

ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
1	10	02-1208	HEX NUT, 1/2" UNF	Steel, Mild	.04
2	10	02-1104	LOCK WASHER, 1/2"	Steel, Mild	.01
3	1	04-1020	WHEEL, SPLIT RIM		17.89
4	1	04-1045	TUBE, INNER	Rubber	2.79
5	1	04-10222	TIRE, B-RANGE	Rubber	9.70
6	10	2-10043	SCREW, HEX CAP, 1/2-20 1" LG.	Steel, Mild	.10



PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance: except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

WHEEL & TIRE ASSEMBLY  
B-RANGE FOR 200 GALLON MODELS

PN: 07-10202

FIG. #5


Drawn: AL

Date: 11/17/2005

Size: A

Scale: NTS

Sheet 1 of 1



NOTE: ITEM #11 LANYARD ASSEMBLY NOT SHOWN

## ITEM #8 SUPPORT: AIRCRAFT SIDE

Parts List

ITEM	QTY	P.N.	DESCRIPTION	MATERIAL	WT.
1	1	04-1032	BALL VALVE, 1/2"	Brass	.46
2	1	P.D.	HOSE MPT-MPT, 12" LG.	Various	.94
3	1	P.D.	FUEL FLOW VIEWING WINDOW	Various	.49
4	1	P.D.	QUICK DISCONNECT, 3/4 MQD	Stainless Steel	.45
5	1	P.D.	BUSHING, 1/2-3/4"	Stainless Steel	.10
6	1	03-1008	CLOSE NIPPLE, 1/2"	Stainless Steel	.08
7	1	P.D.	HOSE SUPPORT CLIP	Stainless Steel	.16
8	1	P.D.	SUPPORT CLIP, HANGER, AIRCRAFT SIDE	Stainless Steel	.57
9	1	P.D.	3_4 MPT 5_8 MPT ADAPTOR	Stainless Steel	.16
10	1	03-00581S	FULL COUPLING, 1/2	Stainless Steel	.07
11	1	P.D.	LANYARD ASSEMBLY	Various	

**SI** SPOKANE  
INDUSTRIES

PO Box 3303 Spokane, WA. 99220 800-541-3601

Tolerance: except  
as noted  
x/x=± 1/8"  
.xx=± .03"  
.xxx=± .005"  
ANG=± 1°

Defuel Adaptor For Warrior UAV

PN: 08-5001

FIG. #6

Drawn: AL

Date: 9/4/2007

Size: A

Scale: NTS

Sheet 1 of 1