



#### CONFIDENTIAL PROPRIETARY INFORMATION

Reproductions of this data or the manufacturing of products from this data by anyone other than Spokane Industries, Inc. of Spokane Washington is strictly prohibited without written consent.

## TECHNICAL MANUAL

### Helifueler 600 Gallon Defueler / Fueler Cart

**Spokane Industries**  
SPOKANE INDUSTRIES, INC.

This document discloses subject matter in which Spokane Industries, Inc has Proprietary rights and such subject matter shall not, without the written permission of Spokane Industries, Inc. be either (A) used, released or disclosed in whole or in part outside the government, (B) used in whole or in part by the government, for manufacture, or (C) used by a party other than the government, except for (1) emergency repair or overhaul work only, by or for the government, where the item or process concerned is not otherwise reasonably available to enable time and performance of the work, provided that release of disclosure hereof outside the government shall be made subject to a prohibition against further use, release of disclosure, or (2) release to a foreign government, or for emergency repair or overhaul work by or for such government under the conditions of (1) above. This legend shall be marked on any reproduction hereof in whole or in part.

©COPYRIGHT 2013 By SPOKANE INDUSTRIES INC.

©COPYRIGHT 2013 By SPOKANE INDUSTRIES INC.

MNUL-005

REVISION A

**APRIL 2013**



Spokane Industries  
3808 N. Sullivan Road, Bldg 4  
Spokane Valley, Washington 99216  
3808 N. Sullivan Road, Bldg 4  
Spokane Valley, Washington 99216  
509-928-0720

## Limited Warranty Agreement Aviation Fuel Products

### To include SealVac™ Vacuum Fuel Drain System, HandiFueler™ Ground Support Service Cart, HeliFueler™, Spokane Industries UAV Fuel Service Cart and Non-Vacuum Units

*Spokane Industries of Spokane Valley, Washington (SI) hereby warrants to the purchaser (the Warranteer) that all products explicitly covered by this Warranty Agreement have been thoroughly inspected upon completion and that they and their component parts are free of defects in materials and workmanship. SI further warrants that in the event the product fails due to defects in materials and/or workmanship within a period of twenty-four (24) months from the effective date of this warranty that SI will provide replacement parts free of charge except for those components which are covered by an Original Equipment Manufacturer's (OEM) Warranty, in which case coverage will be provided by that OEM.*

### Coverage

*The SI Aviation Fuel Products Limited Warranty Agreement covers all products manufactured for use as Aircraft Ground Support Equipment Servicing, UAV Fuel Servicing, Aircraft Fuel Draining Equipment, and Non-Vacuum Units. Certain components of these products are manufactured by third party Original Equipment*

*Manufacturers (OEMs) and are covered by these manufacturers' Warranties. SI Warranty coverage is contingent upon proper installation, operation, maintenance and repair of the product. Refer to the appropriate manuals and documentation for assistance. In cases of uncertainty, SI must be consulted prior to any service work being performed. Failure to do so may result in the termination of Warranty coverage.*

### Terms and Conditions

#### REQUESTS FOR WARRANTY COVERAGE

*Requests for Warranty Coverage should be addressed to: Spokane Industries, Metal Products Division, Quality Assurance Department, 3808 N Sullivan Rd Building 4, Spokane Valley, WA 99216. Calls concerning Warranty Coverage should be placed to 800-541-3601, Fax: 509-927-0826. Please provide the Model Number, Ship Date, Original Purchaser, and Point of Installation, and, if possible, our original Sales Order number. The Quality Assurance Department will make a Warranty determination based upon this information and our internal records. If Warranty coverage is in effect, replacement parts will be sent provided that credit terms have been established. If Warranty coverage is not in effect, the cost of replacement parts will be quoted.*

#### TRANSFERABILITY

*This warranty is extended only to the original purchaser, and is not transferable without the express written consent of SI. Transferability is contingent on the product being in warrantable condition. SI reserves the right to verify product warrantability by whatever means is deemed appropriate, and the right*

*to refuse to transfer the warranty with or without cause. Warranty transfer requests must be made in advance of the sale or transfer of the product. SI accepts no responsibility for any costs associated with the transfer of existing warranties including any costs associated with verification of product warrantability. Requests for Warranty transfers should be sent to the address above.*

## RETURN OF WARRANTY PARTS ("EXCHANGE")

- *For the purposes of quality assurance, SI requires that certain parts and assemblies covered under the SI Limited Warranty Agreement be returned by the Warranteer upon receipt of replacements (known as "Exchange"). In these cases, SI will authorize the shipment of replacement parts immediately and provide a Returned Merchandise Authorization (RMA) number along with a full retail invoice for the replacement parts pending receipt of the Warranty ("defective") parts. The Warranty parts must be returned to SI within 30 days with the RMA number CLEARLY marked on the outside of the shipping materials. At this time SI will inspect the Warranty parts to verify Warranty coverage. If the Warranty parts are deemed defective due to materials and workmanship, SI will issue a full credit for the replacement parts. If the Warranty parts are not returned within thirty days the Warranteer's account will not be credited. Payment in full is then due and subject to the standard terms and conditions of SI credit.*
- *In cases where returned parts are deemed not to be defective, SI reserves the right to refuse to cancel the applicable invoice.*
- *Exchange parts must be properly packed and sealed and shipped to SI by prepaid freight. Under no circumstances does SI accept C.O.D. shipments.*
- *SI Warranty replacement parts are provided subject to the terms and conditions of the SI Sales and Service Agreement which states that where no other Warranty coverage is in place, Service and Warranty parts are covered by a ninety-day limited Warranty.*

## LIMITATIONS

*The following limitations apply to the SI Limited Warranty Agreement:*

- *SI shall not be liable under any circumstances for any incidental or consequential damages including, but not limited to, loss of time, inconvenience, expenses incurred by purchaser in order to remedy defects, or liability purchaser may have with respect to any other person for loss or damage arising from the operation of the product or the product's failure to operate in any way, or any other type of consequential damage or economic loss.*
- *This warranty is limited to defects in materials and workmanship. SI assumes no liability whatsoever for damages arising from the inability of the product to perform a certain task. Damage arising during shipping and handling, improper installation, use, maintenance, repair, or any unauthorized modifications, whether performed by qualified service personnel or not, neglect, Acts of God, etc., are expressly excluded. In any case, SI's liability shall be limited only to the provision of suitable replacement parts for those which failed due to defects in materials and workmanship. Incidental damage resulting from the failure, and labor costs associated with the repair and/or replacement of the product, its assemblies, and component parts, are excluded.*
- *SI reserves the right to limit or terminate warranty coverage in instances where repeated product failures are a result of failure to correct operating conditions which are in any way abnormal or exceed operating condition specifications. It is the purchaser's responsibility to remedy such conditions as may be likely to cause initial and/or repeated failures of the equipment. SI assumes no responsibility whatsoever for any costs incurred for this purpose.*
- *The SI Limited Warranty Agreement covers only replacement parts supplied by SI. SI makes every reasonable effort to ensure an adequate supply of replacement parts. However, in cases where the exact replacement part is no longer available, SI reserves the right to provide a suitable substitute.*
- *Components such as batteries, which are subject to normal wear and tear, are pro-rated under the provisions of this Warranty. Warranty coverage shall be pro-rated according to the amount of Warranty coverage remaining.*

## **EXCLUSIONS**

*The following exclusions apply to the SI Limited Warranty Agreement:*

- *The SI Limited Warranty Agreement applies only to authentic new and, where applicable, refurbished products. Products sold "As Is", demonstration units, and any other products subjected to previous uses are explicitly excluded.*
- *The SI Limited Warranty Agreement excludes any and all parts and assemblies which are covered by another manufacturer's Warranty (see above).*
- *This Limited Warranty Agreement constitutes the complete and entire SI Warranty statement. Any items and/or circumstances not expressly covered by this Warranty Agreement are hereby excluded. This includes, but is not limited to, such additional offerings as SI may make available from time to time. These offerings are independent of this Agreement and, as such, do not in any way extend, modify, or otherwise alter the coverage, terms, conditions, limitations, and exclusions as they are set forth here unless explicitly stated.*
- *The failure to observe any and all of the terms and conditions of this warranty will render it null and void.*
- *Although all reasonable precautions are taken to ensure that shipping damage is avoided. Any damage incurred during the shipment, unloading, and installation of the product is explicitly excluded. Any and all damage during shipment is the sole responsibility of the transportation carrier(s). Product should be thoroughly inspected prior to acceptance from the freight carrier. All SI products are shipped F.O.B. Spokane Washington.*
- *This Warranty is in lieu of all other warranties whatsoever, express, implied and statutory, including, without limitation, the implied warranties of merchantability and fitness for a particular purpose, and all such warranties express or implied, shall be excluded from this transaction and shall not apply to the goods sold.*

***Warranty inquiries are welcomed and should be addressed to:***

**Spokane Industries  
Metal Products Division  
Quality Assurance Department  
3808 N. Sullivan Road Bldg 4  
Spokane Valley, WA 99216  
(800) 541-3601**

## **Section**

|            |   |         |
|------------|---|---------|
| <b>1.0</b> | <b>Introduction</b>   | Page 6  |
| 1.1        | Component Identification  | Page 7  |
| 1.2        | Specifications  | Page 8  |
| 1.3        | Hose Fitting Hookups<br>and Usage for Select Airframes            | Page 9  |
| 1.4        | Daily Inspection Checklist  | Page 10 |
| 1.5        | Preventative Maintenance Chart                                    |         |
| <b>2.0</b> | <b>Safety Guidelines</b>  | Page 11 |
| 2.1        | General Safety Instructions                                       | Page 11 |
| 2.2        | Protective Clothing   | Page 11 |
| 2.3        | Static Bonding and Grounding<br>and Other Fire Hazard Precautions | Page 11 |
| 2.4        | Lockout / Tagout  | Page 11 |
| 2.5        | Area of Use   | Page 11 |
| <b>3.0</b> | <b>Operation Instructions</b>                                     | Page 11 |
| 3.1        | Shipment Preparation  | Page 12 |
| 3.2        | Controls and Indicators   | Page 12 |
| 3.3        | Defueling the Aircraft  | Page 13 |
| 3.4        | Fueling the Aircraft  | Page 14 |
| 3.5        | Taking Samples Using<br>the Sample Ports                          | Page 15 |
| 3.6        | Fuel Moisture Removal<br>Low Point Drain/ Fuel<br>Filter Housings | Page 15 |

## Section

|            |  |         |
|------------|--|---------|
| <b>4.0</b> | <b>Maintenance and Assembly</b>            | Page 16 |
| 4.1        | Repair and Replace Instructions            | Page 16 |
| 4.2        | General Tank Instructions                  | Page 16 |
| 4.3        | Manway Assembly and Maintenance            | Page 17 |
| 4.4        | Front Undercarriage Assembly               | Page 18 |
| 4.5        | Front Wheel Assembly Removal               | Page 18 |
| 4.6        | Front Hub Assembly                         | Page 18 |
| 4.7        | Tow Latch Assembly                         | Page 19 |
| 4.8        | Spindle Assembly                           | Page 20 |
| 4.9        | Steering Arm Assembly                      | Page 20 |
| 4.10       | Tie Rod Assembly                           | Page 20 |
| 4.11       | Front Undercarriage Assembly Removal       | Page 21 |
| 4.12       | Rear Undercarriage Assembly                | Page 21 |
| 4.13       | Rear Wheel Assembly Removal                | Page 21 |
| 4.14       | Rear Hub/Brake Drum Assembly               | Page 22 |
| 4.15       | Mechanical Brake Assembly                  | Page 22 |
| 4.16       | Parking Brake Assembly and Adjustment      | Page 23 |
| 4.17       | Brake Handle and Cable Assembly            | Page 23 |
| 4.18       | Rear Undercarriage Assembly Removal        | Page 24 |
| 4.19       | Wheel Assembly                             | Page 24 |
| 4.20       | Removing the Fuel Pump                     | Page 25 |
| 4.21       | Removing the Fuel Meter                    | Page 25 |
| 4.22       | Removing the Filter Housings               | Page 25 |
| 4.23       | Removing the 4-Way Selection Valve         | Page 25 |
| 4.24       | Removing the Hose Reel                     | Page 25 |
| 4.25       | Changing Fuel Filter Elements              | Page 26 |
| 4.26       | Changing Operator Console Indicator Lights | Page 26 |
| 4.27       | Troubleshooting the DFC                    | Page 27 |
| <b>5.0</b> | <b>Parts Breakdown</b>                     | Page 28 |

### Drawing No.

|             |  |         |
|-------------|--|---------|
| <b>1.0</b>  | <b>Overview, Component Identification</b>        | Page 29 |
| <b>2.0</b>  | <b>Overview, Component Identification (Tank)</b> | Page 30 |
| <b>3.0</b>  | <b>Pump Components</b>                           | Page 31 |
| <b>4.0</b>  | <b>Manway Assembly</b>                           | Page 32 |
| <b>5.0</b>  | <b>Front Undercarriage</b>                       | Page 33 |
| <b>6.0</b>  | <b>Rear Undercarriage and Axle</b>               | Page 34 |
| <b>7.0</b>  | <b>Brake Assembly</b>                            | Page 35 |
| <b>8.0</b>  | <b>Front Hub Assembly</b>                        | Page 36 |
| <b>9.0</b>  | <b>Rear Hub &amp; Drum Assembly</b>              | Page 37 |
| <b>10.0</b> | <b>Wheel &amp; Tire Assembly</b>                 | Page 38 |

## SECTION 1.0

## INTRODUCTION

### IMPORTANT

**YOU MUST READ THIS MANUAL IN ITS ENTIRETY BEFORE OPERATING, SHIPPING OR PERFORMING MAINTENANCE PROCEDURES. FLAMMABLE AND COMBUSTIBLE VAPORS CAN CAUSE FIRE, AND/OR EXPLOSION AND CAN LEAD TO SERIOUS INJURY OR DEATH.**

The instructions in this manual cover the operation and maintenance of the Helifueler Defueler/ Fueler cart manufactured by Spokane Industries, Inc. of Spokane Valley, Washington.

### DESCRIPTION

**.Throughout this manual the unit will be referred to as the DFC.** The Helifueler DFC is a 600-gallon defueler / fueler cart designed to provide a portable, self-contained defueling/fueling system for refueling helicopters. The DFC is easy to use and maintain.


The DFC Helifueler consists of an inner tank assembly and an outer tank, otherwise known as tight wrap construction. This easy to use fueler /defueler consists of a pump, fuel meter, fuel filter and a plumbing system that allows for fuel to recirculate through the system, as well as go in and out of the tank for either defueling or fueling purposes of helicopters.

When fuel is extracted, it is filtered through the plumbing system and placed back into the tank with a 35-foot fuel hose. There is a rigid and a soft extraction wand so that the user can fuel and defuel different size tanks.

Fueling and defueling is made simple with fittings that are designed for specific fueling and defueling purposes for Chinook, Apache and Blackhawk helicopters. Please see section 1.3 for the hose fitting hookups for select airframes.

Additional features of the Helifueler include an air compressor with a hose and an air chuck with a gauge for checking air in the tires of the aircraft, storage capable of storing up to three five liter bottles of fluid, a spill containment kit, and cabinet lighting, which makes it easier and safer to fuel up at night.

Refer to the specifications chart ( Section 1.2) for more information regarding dimensions, fuel capacity and other information on the 600-gallon DFC. Refer to Section 1.4 for the Daily Inspection Checklist and Section 1.5 for The Preventive Maintenance Chart



- 1. Tank
- 2. Manway
- 3. Tow Bar
- 4. Pump Module
- 5. Fuel Filter Housings

- 6. Fuel Meter
- 7. Operator's Console
- 8. Parking Brake
- 9. Fuel Level Gauge
- 10. LED Work Lights

## Section 1.1

**Figure 1-1 Component Identification**

## 1.2 Specifications for the Helifueler

|  |   |
|--|---|
| <b>Dimensions</b>                                | 600 Gallon<br>(Maximum Capacity<br>660 Gallons) |
| <b>Length —<br/>(Tow Bar Up)</b>                 | 156 Inches                                      |
| <b>Length—<br/>(Tow Bar Down)</b>                | 221 Inches                                      |
| <b>Width (Tire to Tire)</b>                      | 77 Inches                                       |
| <b>Height (Tow Bar Up)</b>                       | 72 Inches                                       |
| <b>Height<br/>(Tow Bar Down)</b>                 | 62 Inches                                       |
| <b>Weight—Empty</b>                              | 2,780 Pounds                                    |
| <b>Weight— Full</b>                              | 6,980 Pounds                                    |
| <b>Ground Clearance (at Tow Bar)</b>             | 6 Inches  |
| <b>Ground Clearance<br/>(at Axle)</b>            | 8 inches  |
| <b>Operating Temperature<br/>Range</b>           | -25 to 110 F                                    |
| <b>Storage Temperature Range</b>                 | -40 to 150 F                                    |
| <b>Tire Size (B-Range with Tube Split Wheel)</b> | 20.5 x 8.0-10                                   |

## 1.3 Hose Fitting Hookups and Usage for Select Airframes

| Helicopter Type | Defuel Fittings                                   | Fuel Fittings                                       |
|-----------------|---|---|
| UH-60 Blackhawk | RD-045<br>Custom Plug Fitting                     | Single Point<br>(Whittaker F116)<br>Whittaker Valve |
| AH-64 Apache    | Single Point<br>(Whittaker F116)                  | Single Point<br>(Whittaker F116)<br>Whittaker Valve |
| CH-47 Chinook   | Defuel Elbow (Blue)<br>Threaded Swivel Connection | Single Point<br>(Whittaker F116)<br>Whittaker Valve |



### Part Number Reference

**Black Hawk Fitting RD-045**

**Whittaker Nozzle –AV.COM Part Number F116VX7D**

**Whittaker Valve– 999-14-18**

## 1.4

## Daily Inspection Checklist

| Part to be inspected | What to Look For                           | What to Look For                     | What to Look For  | What to Look for              | Check Off Once Inspected |
|----------------------|--|--------------------------------------|---|-------------------------------|--------------------------|
| Wheels               | Are tires damaged?                         | Are there loose or missing lug nuts? |   |                               |                          |
| Brakes               | Inspect for proper function                | Are brakes properly adjusted?        |   |                               |                          |
| Towbar               | Are there cracks in welds?                 | Are there missing attachment pins?   | Are there missing retaining clips?  |                               |                          |
| Tank                 | Are there leaks or any obvious damage?     | Does Manway close properly?          | Are there loose or missing components in the undercarriage mounting hardware? |                               |                          |
| Fueling Nozzle       | Are there any leaks?                       |                                      |   |                               |                          |
| Ground Reel          | Is cable end securely fastened to cable?   |                                      |   |                               |                          |
| Valves               | Are valves functioning properly?           |                                      |   |                               |                          |
| Fuel Filter Housings | Are there any cracks?                      | Are there any leaks?                 |   |                               |                          |
| Fuel Hose            | Are there any cracks?                      | Are there any leaks?                 | Are there any rub spots?  | Are fitting ends operational? |                          |
| Low-Point Drain      | Is water drained from tank low-point sump? |                                      |   |                               |                          |

## 1.5

## Preventative Maintenance Chart

| Item              | Interval  | Action   |
|-------------------|-----------|--|
| Manway Seal       | Monthly   | Inspect for tears, cracks and compression damage. Refer to Section 4.3 for maintenance instructions.                               |
| Brakes            | Quarterly | Check for proper adjustment and make any adjustments using sections 4.15, 4.16 and 4.17.   |
| 12 Volt batteries | 6 Months  | Check battery cell fluid level. If the batteries need to be serviced, remove the battery box before servicing the batteries.       |
| Tank Weldment     | Yearly    | Inspect both inner and outer tank welds for cracks. Remove plug from outer tank test fitting and inspect for fuel evidence.        |
| Wheel Bearings    | Yearly    | Inspect for damage and replace components when needed. Pack wheel bearings with grease. Use sections 4.8 and 4.17 For maintenance. |

## SECTION 2.0

## SAFETY GUIDELINES

Within this manual are guidelines and safety recommendations for use of the DFC. It is the responsibility of the end user to completely read this manual and comply with all local, state and federal laws and **regulations applicable for defueling and fueling aircraft**. Spokane Industries Inc. is not responsible for industry specific information on safety management, employment safety, health standards, safety codes, etc. Contact your local safety manager or industrial safety representative. It is the responsibility of the end user to ensure persons operating this equipment:

- **Are trained, authorized and permitted to use the equipment.**
- **Have physical and the mental ability to operate this equipment safely.**
- **Are aware of the potential Hazards associated with this equipment, i.e static electricity, electrical shock, fuel spills and pinch points.**

### 2.1 General Safety Instructions

This manual describes physical and chemical processes which may cause injury or death to personnel, or damage to equipment if not properly followed. This safety summary includes general safety precautions that must be understood and applied during operation and maintenance to ensure safety and protection of equipment.

### 2.2 Protective Clothing

When fuels are being handled, approved equipment such as gloves, eye protection, face shields, etc. shall be used.

### 2.3 Static Bonding and Grounding and Other Fire Hazard Precautions

Improper static bonding and grounding can lead to a fire, and as with any other equipment dealing with fuel, there is always a risk of fire if all safety precautions are not followed or the equipment is not used correctly. Make sure to read and understand all instructions before operating this equipment.

### 2.4 Lockout / Tagout

Personnel shall be aware of the hazards associated with unguarded machinery parts, capacitors, gaseous and wet pipe systems, spring loaded devices, etc. Lockout / Tagout the energy source prior to performing maintenance, adjustment or other procedures that would bypass safety guards, barriers, or otherwise expose personnel to hazardous energy sources. Any equipment, machine or process that could unexpectedly energize, start-up or release energy will be equipped with a means to lockout / tagout the energy sources.

### 2.5 Area of Use

This equipment has been designed to operate outdoors only. Flammable and/or combustible vapors in ignitable quantities could be produced under certain circumstances. Additionally, local protocols must be consulted to determine if fuel draining equipment can be used in the location being considered.

## SECTION 3.0

## OPERATION INSTRUCTIONS

### 3.1 Shipment Preparation

#### Warning:

**Flammable and combustible vapors must be removed from tank before shipping to prevent a fire and/or explosion. If this step is not taken, serious injury or death could occur**

Before transporting the DFC by truck or cargo aircraft, make sure to drain the tank of all liquid products by opening the drain valve. Remove all flammable and/or combustible vapors from the Place any loose items in the storage box and and check to make sure the manway assembly is securely attached.

#### Loading the DFC for Truck Shipment

Caution: Fork extensions must be in contact with axle tubes only. Damage to the equipment will occur if the equipment is lifted

from any other location.

Forklift with fork extensions will be required to load the DFC on a truck. Set the parking brake. Approach the unit from the front only. Once the DFC is loaded on the truck, secure to the truck bed using attachment points on tank weldment.

#### Loading the DFC for Air Shipment

Caution: Do not back equipment by any means other than hand pushing/pulling. Or it will cause damage to the equipment.

After placing the DFC in the aircraft, lock tow bar upright, make sure the parking brake is set and that the parking brake, funnel cover, manway assembly and storage boxes are latched.

### 3.2

### Controls and Indicators

| Description                    | Functions  |
|--------------------------------|--|
| Battery Switch                 | Main power disconnect  |
| E-Stop Switch                  | Emergency shut down switch   |
| Fuel Filter petcocks (several) | Maintains the two fuel filters   |
| Fuel Meter                     | Gauge that shows fuel level during defueling and fueling operations  |
| Operator Console               | Turns Defuel / Fuel pumps both ON and OFF  |
| Parking Brake Handle           | Sets Parking Brake   |
| Liquid Level Gauge             | Located on the top centerline of the tank, this shows how much fuel is in the tank.  |
| Sample Port Valves             | There are two of these. One is located on the left side of the fuel meter and the other valve is located on the right side of the recirc valve. These are used to take fuel samples from the tank. |
| LED Worklights                 | Located on top of the helifueler and underneath the top hood, these are used to light the working area.  |

### 3.3 Defueling the Aircraft

#### WARNING

**Never operate the DFC in a closed area or in an area with little or no ventilation**

**All fuels are flammable, do not allow sources of ignition within 50 feet of the DFC.**

#### CAUTION

**Make sure there is enough room in the tank to store the fuel being removed from the aircraft.**

- a. Set brakes by moving the handle so it points upward.
- b. Chock tires if chocks are available.
- c. Attach static bonding/grounding cables by locating reel with clamp end, and pulling cable outward until desired length has been taken out.
- d. Allow cable to retract until it stops. Attach at ramp to an approved bonding/grounding site.
- e. Open pump module covers (left and right) and uncoil 35-foot Hose assembly from hose cradle.
- f. Attach the DEFUEL adapter.
- g. Position the Selection Valve to the DEFUEL position.”
- h. Ensure that the recirc valve is properly positioned.
- i. Turn on the Battery Switch. The “POWER ON” indicator lamp will light up.
- j. Make sure E-stop switches are in the non-stopped condition by twisting them clockwise and allowing them to spring outward.
- k. Place the Pump Selector Switch in the “DEFUEL” position.
- l. Start the fuel pump by pushing the “Pump ON” button.
- m. Monitor fuel meter to remove desired quantity of fuel.

**NOTE: Repeat steps I through M if defueling any other fuel cells on the aircraft**

- n. Turn off fuel pump by depressing the “PUMP OFF”.
- o. Retract the fuel hose from aircraft
- p. Turn off main battery switch.
- q. Recoil hose and store.

### 3.4 Fueling the Aircraft

**WARNINGS:** Never operate the DFC in an enclosed area. Proper ventilation must be maintained at all times. All fuels are flammable, do not allow sources of ignition within 50 feet of the DFC.

**Do not attempt to charge batteries while using the DFC 12 Volt electric fuel pump, damage to charger will occur.**

- a. Set brakes by moving Brake lever upright.
- b. Chock tires if chocks are available.
- c. Locate reel with clamp end, and pull cable outward until desired length has been taken out. Allow cable to retract until it stops. Attach at ramp to an approved bonding /grounding location.
- d. Position the selection valve to the FUEL Position.
- e. Uncoil and fully extend hose.
- f. Remove Nozzle from stowed position and attach to hose end.
- g. Start the fuel pump by depressing the "PUMP ON" button.
- h. On battery box turn main power switch ON by turning clockwise.
- i. Ensure battery charge indicator indicates enough charge for operation.
- j. Open aircraft fuel tank and insert nozzle.
- k. Fill tank to desired capacity.
- l. Remove nozzle, close fuel tank and turn off pump.
- m. Turn main power switch OFF at battery box.
- n. Remove nozzle and stow in nozzle holder.

- o. Retract fuel hose by pulling on retracted hose and allow the hose reel to start retrieving hose, control the rate of retraction by providing a small amount of resistance against the hose reel.


**Caution:** Improper grounding may result in an ignition source.

**NOTE:** Periodically monitor differential pressure gauges during fueling operations. This allows real time reading of filter contamination level. Red scale begins at 15 PSI differential pressure.

### 3.5 Taking Samples Using the Sample Ports

There are two ports used solely for taking fuel samples. The sample port located on the right side of the fuel meter and the sample port located on the left side of the recirc valve.

- a. Make sure parking brake is set
- b. Attach bonding/grounding cables
- c. To take fuel before filtering, unscrew the cap to the sample port located on the right side of the fuel meter (1).
- d. After filtering fuel samples can be taken by unscrewing cap to the fuel sample port located on the left side of the recirc valve.



**Figure 3-1 Sample Ports**

### 3.6 Fuel Moisture Removal Low Point Drain/ Fuel Filter Housings.

The low point drain is located at the rear of the tank assembly.

- a. Make sure that the parking brake is set.
- b. Attach bonding/grounding reels.
- c. Use the fuel pump to empty tank contents into a safe container.
- d. Open low point sump valve and allow remainder of fuel to drain.
- e. Open petcock drain on filter to drain fuel from filter housing.
- f. Remove pipe plugs to drain fuel from plumbing system.

## SECTION 4.0

## MAINTENANCE, ASSEMBLY AND REPAIR

The DFC should always be inspected prior to use to make sure it is in working order.

### 4.1 Repair and Replace Instructions

Remember to set the parking brake while performing maintenance procedures. Approved jack stands and wheel shocks must also be used. Serious injury or death may occur from rolling or falling equipment.

The following procedures are used for the disassembly and reassembly for equipment components.

### 4.2 General Tank

#### Warning

**Make sure that the tank is free of fuel and flammable and/or combustible vapors before performing any maintenance operation involving the tank. Serious injury or death could occur.**

This procedure covers all components attached to the tank by means of threaded pipe connections and describes how to properly apply pipe joint sealing compounds. Pipe joint sealing compounds should be approved for fuel service.

- a. Remove parts that need to be repaired or replaced.
- b. Remove old pipe sealing compound from component (s) by wire brush or approved solvent. If solvent is used, allow parts to dry before moving on to step c.
- c. Inspect threads, and replace any damaged parts.
- d. Apply an even coat of pipe joint sealing compound across and all around the first four threads. The coat thickness should fill the thread "valleys", and no more.
- e. Tighten until hand-tight. Do not cross thread components.
- f. Tighten parts until the connection does not have leaks.

### 4.3 Manway Assembly and Maintenance

The manway assembly is located on the top of the tank. The manway assembly has one adjustment point. Use Figure 4-1 for the following maintenance steps.

#### Manway Disassembly/Reassembly

- a. Open handle (2).
- b. Open Manway Assembly.
- c. Remove nut (7).
- d. Remove gasket retainer (5), gasket (4), and lid (3).
- e. Remove bolt (6) and nut (10) to remove cross-arm (1).
- f. Repair / replace components
- g. Reassemble in reverse order, leaving nut (7) only partially threaded onto cross arm (1).

#### Manway Adjustment

- a. Open handle (2).
- b. Open Manway Assembly.
- c. Rotate nut (11) to adjust lid position. Turn clockwise to move lid closer to the tank. Turn counter clockwise to move the lid away from the tank.
- d. Tighten nut (7) until snug.




Figure 4-1 Manway Assembly

#### 4.4 Front Undercarriage Assembly

The Front Undercarriage assembly consists of a wheel assembly, a hub assembly a spindle assembly a tow latch assembly, a steering arm assembly and an adjustable tie rod assembly.

#### 4.5 Front Wheel Assembly Removal

To remove the wheel assembly, the equipment must have the front end raised and placed on approved jack stands.

- a. Loosen lug nuts on wheel assembly requiring maintenance one turn while equipment is still on the ground.
- b. Raise equipment with suitable maintenance jack (see Figure 4-2, arrow A for jack placement) high enough to remove wheel assembly.
- c. Place approved jack stands under front axle (see Figure 4-2, arrow B for stand placement).
- d. Remove lug nuts of wheel assembly needing maintenance, and remove.





Figure 4-3 Front Hub Assembly

Figure 4-2 Lift Points


#### 4.7 Tow Latch Assembly

The tow latch assembly is used to secure the tow bar in the upright position. see Figure (4-4).

- a. Remove tow bar (1) by placing the tow bar in upright, latched position.  
Remove pin (2). While holding onto towbar, place foot on toe latch assembly (See reference arrow A) and depress.
- b. Pull hitch pin (3) from steering arm assembly and place tow bar to the side.

(The remaining steps are illustrated in Figure 4-5).

- c. Remove bolt (7) and nut (10).
- d. Rotate toe latch plate (9) downward to free from assembly.
- e. Detach spring (8) from toe latch plate (9) and spring anchor (24).



**Figure 4-4 Tow Bar Removal**

**NOTE:**

Removing hitch pin from steering arm assembly will free tow bar. Prevent tow bar from falling by holding it firmly until free. Set aside.

## 4.8 Spindle Assembly

To remove the spindle assembly, follow the maintenance steps for the front hub assembly before beginning the next steps. See Figure 4-5.

- a. Remove nut (17) and washer (16).
- b. Remove nut (21) and washer (20).
- c. Remove king pin (14) from yoke by using a rubber hammer.
- d. Grasp spindle assembly (18) and rotate toward front of tank until the yoke is free.
- e. Remove spindle assembly from tie rod (15).
- f. Remove bushings (19) with bronze punch and hammer.
- g. Repair / replace components.

## 4.9 Steering Arm Assembly

- a. Remove the thin lock nut (1).
- b. Remove nuts (17) and flat washers (16).
- c. Remove bolts (22) and nuts (5). Allow lower steering arm subassembly (11), bushing (3), and tie rod assembly 12 to drop down; place to the side.

- d. Lift upper steering arm subassembly vertically to clear pivot pin (reference arrow (A), then pull to clear tank and front axle tube.
- e. Remove tie rod assembly (12) by removing nut (6) and flat washer (4). Note the presence of the bushings (23).
- f. Repair / replace components.

## 4.10 Tie Rod Assembly

Refer to Figure 4-5 for the removal of the tie rod. Before beginning this process make sure that you have followed the steps for the steering arm assembly. **Note presence and location of bushings (23) when removing tie rod assembly from steering arm assembly.**

- a. Disassemble the tie rod assembly by the unthreaded components. Before disassembly mark rod length with masking tape. Note that tie rod ends angle downward when reassembling.
- b. Adjust tire toe in/toe out as needed.




Figure 4-5 Exploded View of Undercarriage

#### 4.11 Front Undercarriage Removal

To remove the entire Front Undercarriage assembly, the equipment must have the front end raised. See Figure 4-2 for lift points.

- a. Raise equipment with suitable maintenance jack (see Figure 4-4 arrow A for jack placement) to allow four inches of space between the wheels and ground.
- b. Place cribbing under tank skids (see Figure 4-2, reference arrows C) to safely support the equipment.
- c. Lower onto cribbing. Leave jack in place.
- d. Raise jack to apply slight pressure on assembly. **(Tow bar must be in upright position.)**
- e. Remove bolts (2) and nuts (3).
- f. Carefully lower jack and assembly until wheels are on the ground and front axle tube clears tank mounts.
- g. Pull Front Undercarriage forward. Note location of rubber mounting pads (5).

#### WARNING

**Use suitable lifting and support equipment when performing these steps. Serious injury or death could occur from rolling or falling equipment.**




Figure 4-6 Front Undercarriage Removal




Figure 4-7 Rear Undercarriage Removal

#### 4.12 Rear Undercarriage Assembly

See Figure 4-7 for the following maintenance steps. The rear undercarriage assembly consists of: a wheel assembly, a hub and brake drum assembly (1), a mechanical parking brake assembly (2), a rear spindle (4), and the axle (10).

#### 4.13 Rear Wheel Assembly Removal

To remove wheel assembly, the equipment must have the back end raised and placed on approved jack stands. Points A and B are similar on both the rear and front axles.

- a. Raise equipment with suitable maintenance jack high enough to remove wheel assembly. (See Figure 4-2, arrow A for jack placement).
- b. Place approved jack stands under rear axle (see Figure 4-2, arrow B for stand placement).
- c. Remove lug nuts of wheel assembly needing maintenance.

#### 4.14 Rear Hub / Brake Drum Assembly

To remove the rear hub and brake drum assembly, follow the maintenance steps for the rear wheel assembly removal before beginning the next steps. Figure 4-8 illustrates the process for the rear hub/ brake drum assembly.

- a. Remove dust cap (1) by lightly tapping with a rubber hammer.
- b. Remove cotter pin (2), castle nut (3) and washer (4).
- c. Grasp front hub (7) and drum (8) and pull outward firmly. Ensure that bearing (5) doesn't fall from hub and strike the ground.
- d. Remove bearing (5), seal (11), and bearing(10) from the rear hub (7).
- e. Using a suitable H-frame press, remove bearing races (6) and (9).
- f. Remove drum (8) by pressing out wheel studs (12) in suitable H-frame press.
- g. Replace components and grease bearings before reassembly.
- h. Reassemble in reverse order. Castle nut (3) should be tightened until the hub assembly rotates barely past free.




Figure 4-9 Mechanical Brake

#### 4.15 Mechanical Brake Assembly

The assembly can be disassembled while attached to the rear spindle or removed from the unit. See Figure 4-9.




Figure 4-8 Rear Hub and Brake Drum

- a. Remove Rear Wheel Assembly as described in section 4.13.
- b. Remove Rear Hub and Brake Drum Assembly as described in section 4.14.
- c. Remove brake cable end from arm (5) as described in section Section 4.17, step (a).
- d. Remove nuts (12), washers (13), and bolts (14) shown in Figure 4-9
- e. Remove Mechanical Brake Assembly and place on flat surface.
- f. Remove spring (3).
- g. Release brake shoes (2) by removing springs (9) from the backing plate (1).
- h. Remove nut (7), lock washer (8), and bolt (6) to release arm (5).
- i. Remove brake cam (4) by pulling directly outward.

NOTE: Steps (d) and (e) are needed only if Mechanical Brake Assembly is to be removed from the axle.

## 4.16 Parking Brake Assembly and Adjustment

The parking brake assembly consists of a brake handle and cable assembly and a mechanical brake assembly. The parking brake can be adjusted at three different locations.

An in-field adjustment can be made at the brake handle by turning the handle cap clockwise to tighten brakes and counterclockwise to loosen the brakes (see reference arrow D in Figure 4-10.) This adjustment must be made with the brake handle in the off position. Maintenance level adjustments can be made at reference arrow E and reference arrow F of Figure 4-10 (each side).

## 4.17 Brake Handle and Cable Assembly

The brake handle and cable assembly only need to be disassembled to the point that the repair is needed. These instructions start at the wheel assembly and progress toward the brake handle. (11)

- a. Remove cotter pin (13) and clevis pin (14) to release clevis (12).
- b. Unthread clevis (12) from cable
- c. Remove nut (15) and remove cable housing (10) from bracket.
- d. Remove nut at opposite end of cable and disassemble cable linkage parts (6), (7), (8), and (9).
- e. Repeat steps (a) through (d) for opposite side.
- f. Remove nut (4) to release cable equalizer (5).
- g. Repeat step c. for cable housing leading to brake handle.
- h. Remove nut at other end of cable and release cable by disassembling cable linkage from brake handle (1).
- i. Remove bolts (2) and nuts (3) to free brake handle (1).




Figure 4-10 Brake and Cable Assembly

## 4.18 Rear Undercarriage Assembly

To remove the entire Rear Undercarriage assembly, the equipment must have the back end raised. See Sections 4.12, and 4.13 with Figure 4-11.

- a. Raise equipment with suitable main maintenance jack (see Figure 4-11 reference arrow A for jack placement) and allow for 2-inches of space between the wheels and the ground.
- b. Place cribbing under tank skids to safely support the equipment. (see Figure 4-11, reference points labeled with a C).
- c. Lower onto cribbing. Leave jack in place.
- d. Disconnect parking brake cables at mechanical brake assembly in Section 4.15, step (a).
- e. Raise jack to apply slight pressure on assembly.
- f. Remove mounting nuts and bolts from both sides of axle assembly.
- g. Carefully lower jack and assembly until wheels are on the ground and the front axle tube clears tank mounts.




Figure 4-11 Lift Points




Figure 4-12 Wheel Assembly

## 4.19 Wheel Assembly

The Wheel assembly is a two-piece, split rim design. Use Figure 4-12 and sections 4.12 and 4.13 for the following maintenance steps.

- a. Remove wheel assembly as described in Section 4.17 for the side needing repair.
- b. Release air pressure from the inner tube by depressing stem valve or by removing the stem valve.
- c. Remove nuts (7), lock washers (6), and bolts (1).
- d. Separate split-rims (2) and (5) from tire (3).
- e. Remove inner tube (4) from tire (3). When reassembling, make sure that the inner tube stem is positioned through access hole in split-rim.
- f. Torque nuts (6) to 150-foot-pounds before applying air pressure to wheel.

## **WARNINGS:**

**Disconnect all electrical connections to the unit (batteries, battery charger, tow vehicle) before performing any of the steps described here. Flammable liquids and vapors and be ignited by accidental electrical arcs. Serious injury or death could result.**

**Drain all flammable liquids from the tank and plumbing system before performing any of the steps described here. Flammable liquids and vapors pose a fire danger that could result in serious injury or death.**

### **4.20 Removing the Fuel Pump**

- a. Remove electrical leads from pump motor. The cover plate is located in back of the pump motor and the conduit is located in front of the pump motor.
- b. Remove the two bolts connecting the fuel meter (6) to the pump-to-meter line (9).
- c. Remove the pump to meter line (9).
- d. Remove the four bolts at the bottom of the pump mounting plate.
- e. Remove the threaded hose from the pump's inlet.

### **4.21 Removing the Fuel Meter**

- a. Remove the two bolts connecting the fuel meter (6) to the pump-to-meter line (9).
- b. Remove the four bolts connecting the fuel meter (7) to the back of the pump.

### **4.22 Removing the Filter Housings**

- a. Remove the Victaulic fitting on the left side of the housing filter.
- b. Unthread the recirc valve (8).


### **4.23 Removing the 4-Way Selection Valve**

- a. Remove fuel meter (6) as described in Section 4.20.
- b. Remove the valve-to-pump line (2).
- c. Remove the valve-to-pump line threaded Victaulic fitting at the elbow next to the 4-way selection valve. (10)

- d. Remove the tank-to-valve line (5) Victaulic fitting at the elbow next to the selection valve.
- e. Remove the U-bolt (not shown) that secures the remaining assembly to the frame.
- f. Using a pipe wrench and a bench vise, Remove remaining components.

### **4.24 Removing the Hose Reel**

- a. Remove all items connected to mounting bracket (12) and remove bracket.
- b. Remove valve-to-reel line. (7)
- c. Remove the quick disconnect from the fueling nozzle (14).



**Figure 4-13 Pump Module**

#### 4.25 Changing Fuel Filter Elements

The fuel filter elements should be replaced whenever fuel flow is restricted or at least once per year. The following steps describe how to replace the fuel filter. See Figure 4-14.

- a. Drain filter housing by opening the top and bottom petcock valves.
- b. Remove the four bolts that secure the filter canister to the filter housing.
- c. Pull downward on the filter element.
- d. Replace O-ring (not shown.)
- e. Install new filter element in reverse order.
- f. Close bottom petcock valve.
- g. Jog pump to purge air.
- h. Close top petcock valve.

#### 4.26 Changing Operator Console Indicator Lights

The only maintenance activity for the operator console is to change out indicator lights.

- a. Identify the indicator light that needs to be removed.
- b. Rotate lens counterclockwise and remove.
- c. Remove circular diffuser disk (plastic) from housing.
- d. Remove and replace light bulb.




Figure 4-14 Fuel Filters

## 4.27

## Troubleshooting the Helifueler DFC

| Problem   | Probable Cause   | Corrective Action  |
|---|--|--|
| <b>Threaded Connection leaking weeping</b>        | Loose fitting, bad seal, damaged fitting   | Use Section 4.2 To fix condition   |
| <b>Valve Leaking, weeping, or doesn't operate</b> | Internal damage to valve's ball, stem, or seat   | Replace valve using section 4.2  |
| <b>Manway won't seal</b>                          | Manway Assembly is out of adjustment or seal is damaged  | Adjust manway assembly using section 4.3   |
| <b>Low/ No discharge pressure at fuel nozzle</b>  | Low battery charge<br>Fuel filter(s) restricted<br>Tank-to-Pump valve partially open<br>Fuel/Defuel T-handle not pushed in   | Charge batteries<br>Inspect and replace if needed<br>Ensure valve is open (handle vertical)<br>Ensure T-handle is pushed in completely   |
| <b>Low/ No Defueling Capability</b>               | Low battery charge<br>Fuel filter(s) restricted<br>Tank-to-Pump valve partially open<br>Fuel/Defuel T-handle not pulled out  | Charge batteries<br>Inspect and replace if needed<br>Ensure valve is open (handle vertical)<br>Ensure T-handle is pulled out completely  |
| <b>12 Volt pump – weak or will not work</b>       | Low/ No battery charge<br>Battery terminals/ cables corroded<br>Battery Cell(s) fluid low<br>Main Power switch in OFF position<br>Pump has internal damage<br>Pump has reached duty cycle<br>Circuit breaker has tripped | Fully charge batteries<br>Inspect & clean, replace if necessary<br>Service cell(s) with distilled water<br>Turn Main Power switch ON<br>Replace pump<br>Wait 30 minutes and retry<br>Wait 30 minutes and retry |
| <b>Fuel Meter has no indication of flow</b>       | Main pump not turned ON<br>Main tank empty<br>Fuel Meter internally broken   | Turn ON pump<br>Load fuel into tank<br>Replace fuel meter  |
| <b>Wheels won't steer properly</b>                | Steering arm assembly is damaged or tie rod assembly is damaged or misadjusted.  | Inspect and repair when needed using Sections 4.9 and 4.10.  |
| <b>Wheels wobble or drag while rolling</b>        | Wheel bearings are damaged or loose  | Inspect and Repair if needed   |
| <b>Towbar won't lock in upright position</b>      | Tow latch spring, damaged or missing   | Inspect and replace when necessary   |
| <b>Brakes don't secure unit while engaged.</b>    | Brakes are out of adjustment o parking brake assembly is damaged or missing  | Adjust brakes or adjust and repair using sections 4.15, 4.16 and 4.17.   |

## **SECTION 5.0**


## **PART BREAKDOWN DRAWINGS**

The following figures are supplied to assist in component identification and parts reordering. When reordering, ensure the complete model number and serial number are provided to the sales representative.

You may access customer service by contacting the Metal products Division at 800-541-3601, or 509-928-0720. (The toll free number does not work internationally). If you would like more information about the Spokane metal products division of Spokane Industries you may visit the website at [www.spokaneindustries.com](http://www.spokaneindustries.com).

### **DRAWING NUMBER**


- 1.0      Overview, Component Identification**
- 2.0      Overview, Component Identification (Tank)**
- 3.0      Pump Components**
- 4.0      Manway Assembly**
- 5.0      Front Undercarriage**
- 6.0      Rear Undercarriage and Axle**
- 7.0      Brake Assembly**
- 8.0      Front Hub Assembly**
- 9.0      Rear Hub & Drum Assembly**
- 10.0     Wheel & Tire Assembly**



## DRAWING 1.0

## Overview Component Identification


| ITEM | QTY | P.N.      | DESCRIPTION                 | MATERIAL        | WEIGHT        |
|------|-----|-----------|-----------------------------|-----------------|---------------|
| 1    | 1   | 08-1901   | Tank, Sub-assy,             | Stainless Steel | 2035.5lbmass  |
| 2    | 1   | RD-040-02 | Pump Module Assy,           |                 | 972.8 lb.mass |
| 3    | 1   | 06-1023   | Mounting Pad                |                 |               |
| 4    | 4   | 02-3087   | Nut, Nylon Insert, 1/2" UNC |                 |               |
| 5    | 4   | 02-3025   | Bolt 1/2-13 x 4 1/2 LG      |                 |               |
| 6    | 2   | 02-3093   | Nut, Nylon Insert, 1/2-12   |                 |               |
| 7    | 1   | 04-0030   | 12x12x32 Black Utility Box  | Aluminum        | 13.1lbmass    |



## DRAWING 2.0

## Overview, Component Identification (Tank)


| ITEM | QTY | P.N.     | DESCRIPTION                    | MATERIAL        | WEIGHT         |
|------|-----|----------|--------------------------------|-----------------|----------------|
| 1    | 1   | 08-1901  | Tank, Subassy, 600 S           | Stainless Steel | 2470.5 lb.mass |
| 2    | 1   | 08-10251 | Cross Arm and Lid Assembly     | Stainless Steel | 15.75 lb.mass  |
| 3    | 1   | 04-01545 | Tank Vent, Fill, 2"            | Brass           | 1.99 lb.mass   |
| 4    | 1   | 04-01540 | Liquid Level Gauge             | Various         | .08 lb.mass    |
| 5    | 6   | 02-12041 | Nut, Nylon Insert, 1/2" UNC    |                 |                |
| 6    | 4   | 02-1503  | Hex Bolt, 1/2" UNC x 4 1/2" LG |                 |                |
| 7    | 2   | 06-1023  | Pad, Mounting                  |                 |                |



**Drawing 3.0**

**Pump Components**



| ITEM | QTY | P.N.           | DESCRIPTION                                      |
|------|-----|----------------|--|
| 1    | 1   | 04-0702        | Fire Ext. 5# Purple K                            |
| 2    | 1   | 04-10361       | Grounding Reel, Red, With Clamp                  |
| 3    | 1   | 105-00004-A024 | Electrical Box Assembly                          |
| 4    | 1   | ED-041-25-5031 | Hose Assy, 1-INx38 IN                            |
| 5    | 1   | 25-5020        | Plumbing Kit, Air Tank X Hose Reel               |
| 6    | 1   | 15-0010        | 3x2 Operators Console                            |
| 7    | 1   | 04-8025        | Spill Response Kit #420                          |
| 8    | 1   | 04-0143        | Meter, MR 5-30N GPI, 1 1/2 IN # 126300-25        |
| 9    | 2   | 04-8043        | Filter Housing, Facet VF-225B-PGS                |
| 10   | 2   | 04-8040        | Fuel Sampling Port                               |
| 11   | 1   | 04-0174GP      | Pump, Fuel, 12VDC, 25GPM, 35 AMP, GPI 1333262-03 |
| 12   | 1   | 04-10310       | Valve, 4-Way Lever Operated, 1- 1/2 IN. Ports    |
| 13   | 1   | 04-10350       | Valve, Ball, 3-Way, 1 1/2 IN NPT                 |
| 14   | 2   | 25-5008        | Suction Hose Assy, 1" x 30 "                     |
| 15   | 1   | 25-5009        | Suction Wand                                     |



**Drawing 4.0**

**Manway Assembly**

| ITEM | QTY | P.N.     | DESCRIPTION                    |
|------|-----|----------|--------------------------------|
| 1    | 1   | 07-1039S | Cross Arm                      |
| 2    | 1   | 01-8222S | Flip Lock                      |
| 3    | 1   | 02-3042  | Bolt, 3/8-16 x3 " LG (AP)      |
| 4    | 1   | 02-3044  | Bolt, 3/8-16 x3 1/2 " LG (AP)  |
| 5    | 2   | 02-3089  | Nut, Nylon Insert, 3/8-16 (AP) |
| 6    | 1   | 01-86001 | Manway Lid, 16"                |
| 7    | 1   | 06-25025 | Manway Gasket                  |
| 8    | 1   | 01-8710  | Retainer Gasket, SV            |
| 9    | 2   | 02-3091  | Nut, Nylon Insert              |




**Drawing 5.0**

**Front Undercarriage**

| ITEM | QTY | P.N.     | DESCRIPTION                       |
|------|-----|----------|-----------------------------------|
| 1    | 1   | 02-12071 | Nut, Nylon Insert, 3/4-16 UNF     |
| 2    | 2   | 03-1014  | Bushing, Stewering Arm            |
| 3    | 1   | 02-12141 | Jam Nut, Nylon Insert 3/4-16" UNF |
| 4    | 1   | 07-1052  | Steering Arm, (400 & 600 Only)    |
| 5    | 1   | 02-1501  | Hex Bolt, 5/16-18 x 4 1/2" LG     |
| 6    | 1   | 02-1300  | Pin, Cotter                       |
| 7    | 1   | 03-1013  | Bushing, King Pin                 |
| 8    | 1   | 07-10105 | Toe Latch                         |
| 9    | 1   | 02-11072 | Flat Washer                       |
| 10   | 2   | 03-1015  | Bushing, Tie Rod                  |
| 11   | 1   | 02-1201  | Nut, Nylon Insert, 5/16-18        |
| 12   | 1   | 02-1304  | Hitch Pin                         |


| ITEM | QTY | P.N.     | DESCRIPTION                               |
|------|-----|----------|---|
| 13   | 2   | 02-12041 | Nut, Nylon Insert, 1/2" UNC               |
| 14   | 1   | 07-1046  | Steering Arm, Lower Plate (400, 600 Only) |
| 15   | 2   | 02-1502  | Bolt, 1/2-13 x 1 3/4" LG                  |
| 16   | 1   | 07-1005  | Tie Rod (400, 600 Only)                   |
| 17   | 1   | 02-12141 | Nut, 3/4-16 UNF                           |
| 18   | 2   | 03-1013  | Bushing, King Pin                         |
| 19   | 1   | 02-12131 | Nut, Nylon Insert,                        |
| 20   | 2   | 03-1014  | Bushing, Steering Arm                     |
| 21   | 1   | 02-12141 | Jam Nut, Nylon Insert 3/4-16" UNF         |
| 22   | 1   | 07-1052  | Steering Arm, (400 & 600 Only)            |
| 23   | 1   | 07-1009  | Housing, King Pin                         |
| 24   | 1   | 07-11071 | Front Axle                                |



**Drawing 5.0**

**Rear Undercarriage and Axle**


| ITEM | QTY | P.N.     | DESCRIPTION                   |
|------|-----|----------|-------------------------------|
| 1    | 1   | 05-1023  | Rear Axle Tube 400/600 Gallon |
| 2    | 1   | 07-1010  | Rear Spindle Weldment         |
| 3    | 8   | 02-3024  | Bolt 1/2-13 x 4 Inch LG       |
| 4    | 2   | 02-3087  | Nut, Nylon Insert 1/2-13      |
| 5    | 8   | 02-3072  | Nut, 1/2-13 Plated            |
| 6    | 2   | 02-3068  | Nut, 1/2-13 Plated            |
| 7    | 8   | 02-3026  | Bolt, 1/2-13 by 1 1/2 Inch LG |
| 8    | 8   | 02-3050  | Bolt, 3/8-16 AP               |
| 9    | 8   | 02-3143  | Lock Washer                   |
| 10   | 2   | 02-3024  | Bolt, 1/2-13 x 4 Inch         |
| 11   | 4   | 02-3025  | Bolt                          |
| 12   | 1   | 08-10301 | Rear Axle Assembly            |
| 13   | 2   | 08-1007R | Brake Assembly                |
| 14   | 2   | 08-12050 | Rear Hub and Drum Assembly    |
| 15   | 2   | 06-1012  | Rear Mount Pad                |



**Drawing 7.0**

**Brake Assembly**


| ITEM | QTY | P.N.      | DESCRIPTION                             |
|------|-----|-----------|---|
| 1    | 1   | 04-1064R  | Back Plate                              |
| 2    | 1   | 04-1030R  | Cam Lever                               |
| 3    | 1   | 02-10017R | Hex Head Cap Screw, 5/16"-UNF 1 1/2" LG |
| 4    | 2   | 02-12011  | Lockwasher 5/16"                        |
| 5    | 1   | 02-11011  | Return Spring                           |
| 6    | 1   | 04-10265R | Brake Shoe Hold Down Spring             |
| 7    | 2   | 04-1026R  | Bushing, King Pin                       |
| 8    | 2   | 04-10265R | Brake Shoe                              |
| 9    | 1   | 0401928R  | Cam                                     |



**Drawing 8.0**

**Front Hub Assembly**


| ITEM | QTY | P.N.     | DESCRIPTION         |
|------|-----|----------|---------------------|
| 1    | 1   | 04-1017  | Hub, Front Axle     |
| 2    | 1   | 04-1016  | Cup, Outer Bearing  |
| 3    | 1   | 04-1014  | Cone, Outer Bearing |
| 4    | 2   | 02-12055 | Washer              |
| 5    | 1   | 02-1205  | Nut, Castle         |
| 6    | 1   | 04-1015  | Cup, Inner Bearing  |
| 7    | 2   | 04-1013  | Cone, Inner bearing |
| 8    | 2   | 04-1012  | Seal bearing        |
| 9    | 1   | 04-1019  | Cap, Hub            |
| 10   | 1   | 04-1017  | Stud                |
| 11   | 5   | 02-1303  | Pin, Cotter         |
| 12   | 1   | 05-1021  | Nut, lug            |



Drawing 9.0

Rear Hub and Drum Assembly

| ITEM | QTY | P.N.     | DESCRIPTION         |
|------|-----|----------|---------------------|
| 1    | 1   | 05-1020  | Hub, Rear Axle      |
| 2    | 1   | 04-1016  | Cup, Outer Bearing  |
| 3    | 1   | 04-1014  | Cone, Outer Bearing |
| 4    | 2   | 02-12055 | Washer              |
| 5    | 1   | 02-1205  | Nut, Castle         |
| 6    | 1   | 02-1303  | Pin, Cotter         |
| 7    | 2   | 04-1019  | Cap, Hub            |
| 8    | 2   | 04-1015  | Cup, Inner Bearing  |
| 9    | 1   | 04-1013  | Cone, Inner bearing |
| 10   | 1   | 04-1012  | Seal, Bearing       |
| 11   | 5   | 02-1017  | Stud                |
| 12   | 1   | 05-1021  | Drum, Brake         |
| 13   | 5   | 04-1021  | Nut Lug             |



**Drawing 10.0**

**Wheel and Tire Assembly**

| ITEM | QTY | P.N.     | DESCRIPTION                           |
|------|-----|----------|---------------------------------------|
|      | 4   | 07-10201 | Complete Wheel Assembly (All Numbers) |
| 1    | 1   | 04-10221 | Tire, 20.5x 8.0-10, E-Range           |
| 2    | 1   | 04-1045  | Inner Tube                            |
| 3    | 2   | 04-1020  | Split Rim Wheel Assembly              |